

SPECIFICATIONS

Physical Properties:

1. Ultimate Tensile Load = 266.9 kN (60.0 kips) minimum per Anchor.
2. Actual Pullout Strength depends on foundation design and concrete properties.

Installation Instructions:


See other side of page for typical installation diagrams.

1. Fabricate flat steel or wood template with four (4) 25 mm (1") diameter holes located to match the specified bolt pattern of the pole base plate.
2. Attach four (4) Pole-Safe® Type B Female Anchors to template using four (4) 25 mm (1") diameter bolts. Ensure that each Anchor Washer is flush and snug against the bottom of the template.
3. Lower Anchor Assembly into fresh concrete foundation, and vibrate into position such that the tops of the Anchor Washers are flush with the finished top surface of the foundation.
4. Support template such that all Anchors are level and in their proper locations.
5. Allow concrete to cure, and then remove bolts and template from the top of the foundation.


Transpo® Type B Female Anchor
 for use with Pole-Safe® Model No. 5100
 Breakaway Support System for Light Poles



20 Jones Street
 New Rochelle, NY 10801
 914-636-1000



See other side of page for complete
Installation Instructions



Transpo® Type B Female Anchor
for use with Pole-Safe® Model No. 5100
Breakaway Support System for Light Poles



20 Jones Street
New Rochelle, NY 10801
914-636-1000